



Performing Quality Flow Measurements at Mine Sites



Performing Quality Flow Measurements at Mine Sites

by

Science Applications International Corporation
Environment and Health Sciences Group
Idaho Falls, ID 83401

EPA Contract No. 68-C-98-006
Task Order 14 & 29

for

Sustainable Technology Division
National Risk Management Research Laboratory
Cincinnati, Ohio 45268

National Risk Management Research Laboratory
Office of Research and Development
U.S. Environmental Protection Agency
Cincinnati, OH 45268

NOTICE

The U.S. Environmental Protection Agency through its Office of Research and Development funded and managed the compilation of information included in this guidebook under Contract 69-C-98-006 to Neptune and Co. It has been subjected to the Agency's peer and administrative review and has been approved for publication as an EPA document. Mention of trade names or commercial products does not constitute endorsement or recommendation for use.

FOREWORD

The U.S. Environmental Protection Agency is charged by Congress with protecting the Nation's land, air, and water resources. Under a mandate of national environmental laws, the Agency strives to formulate and implement actions leading to a compatible balance between human activities and the ability of natural systems to support and nurture life. To meet this mandate, EPA's research program is providing data and technical support for solving environmental problems today and building a science knowledge base necessary to manage our ecological resources wisely, understand how pollutants affect our health, and prevent or reduce environmental risks in the future.

The National Risk Management Research Laboratory is the Agency's center for investigation of technological and management approaches for preventing and reducing risks from pollution that threatens human health and the environment. The focus of the Laboratory's research program is on methods and their cost-effectiveness for prevention and control of pollution to air, land, water, and subsurface resources; protection of water quality in public water systems; remediation of contaminated sites, sediments and ground water; prevention and control of indoor air pollution; and restoration of ecosystems. NRMRL collaborates with both public and private sector partners to foster technologies that reduce the cost of compliance and to anticipate emerging problems. NRMRL's research provides solutions to environmental problems by: developing and promoting technologies that protect and improve the environment; advancing scientific and engineering information to support regulatory and policy decisions; and providing the technical support and information transfer to ensure implementation of environmental regulations and strategies at the national, state, and community levels.

This publication has been produced as part of the Laboratory's strategic long-term research plan. It is published and made available by EPA's Office of Research and Development to assist the user community and to link researchers with their clients.

E. Timothy Oppelt, Director
National Risk Management Research Laboratory

ABSTRACT

Accurate flow measurement data is vital to research, monitoring, and remediation efforts at mining sites. This guidebook has been prepared to provide a summary of information relating to the performance of flow measurements, and how this information can be applied at mining sites. Information presented in this guidebook includes the theory, methods, selection criteria for these methods, and quality assurance/quality control (QA/QC) guidance for performing flow measurements at mining sites.

TABLE OF CONTENTS

NOTICE	ii
FOREWORD	iii
ABSTRACT	iv
LIST OF ACRONYMS	ix
1.0 INTRODUCTION	1
1.1 PURPOSE AND NEED OF GUIDEBOOK	1
1.2 ORGANIZATION OF GUIDEBOOK	2
2.0 BASIC CONCEPTS OF OPEN CHANNEL FLOW MEASUREMENT	3
2.1 BASIC WATER MEASUREMENT CONCEPTS	3
2.1.1 Gage Datum	3
2.1.2 HEAD	4
2.1.3 STAGE	4
2.1.4 VELOCITY	4
2.1.5 Discharge	7
2.2 OPEN CHANNEL FLOW RELATIONSHIPS	8
2.2.1 Continuity Equation	8
2.2.2 Energy Equation	9
2.2.3 Momentum Equation	11
3.0 MEASUREMENT METHODS	13
3.1 GAGES	13
3.1.1 General Criteria for Selecting Sites to Establish Gages	13
3.1.2 Non-Recording Gages	14
3.1.3 Recording Gages	16
3.2 WEIRS	18
3.2.1 Siting Criteria for Weirs	19
3.2.2 Sharp-Crested Weirs	19
3.2.3 Broad-Crested Weirs	24
3.3 FLUMES	25
3.3.1 Siting Criteria for Flumes	26
3.3.2 Long-Throated Flumes	27

3.3.3	Short-Throated Flumes	29
3.4	CURRENT METERS	34
3.4.1	Siting Criteria for Current Meters	34
3.4.2	Types of Current Meters	34
3.4.3	Methods to Determine Flow Velocity	36
3.4.4	Computing Stream Discharge	37
3.5	ACOUSTIC VELOCITY METERS	37
3.5.1	Siting Criteria for Acoustic Velocity Meters	38
3.5.2	Types of Acoustic Velocity Meters	39
3.6	TRACERS AND DYE DILUTION METHODS	40
3.6.1	Siting Criteria and Sources of Error	40
3.6.2	Types of Tracers	41
3.6.3	Methods to Determine Stream Discharge	43
4.0	COMPARISON OF METHODS AND SELECTION CRITERIA	46
4.1	METHOD SELECTION GUIDELINES AND ACCURACY	46
4.2	COMPARISON OF METHODS	51
4.3.1	Measuring Discharge From Adits	59
4.3.2	Measuring Discharge From Tailings Ponds	61
4.3.3	Measuring Discharge in Remote Areas with Unstable Channel Conditions	62
5.0	QUALITY ASSURANCE/QUALITY CONTROL FOR FLOW MEASUREMENTS	63
5.1	OVERVIEW OF THE QA/QC PROCESS AND DEVELOPING A QUALITY ASSURANCE PROJECT PLAN	63
5.2	QA/QC COMPONENTS	63
5.2.1	QA Management	63
5.2.2	Quality Assurance Objectives	64
5.2.3	Measurement and Data Acquisition	69
5.2.4	Assessment and Oversight	70
5.2.5	Data Validation, Usability, and Reporting	72
6.0	REFERENCES	76
APPENDIX A		A-1

LIST OF FIGURES

Figure 2-1. Typical Open Channel Velocity Profile	6
Figure 2-2. Typical Velocity Distributions for Several Channel Profiles	6
Figure 2-3. Graphical Representation of the Terms in Bernoulli's Equation for an Open Channel	9
Figure 2-4. Typical Specific Force plus Momentum Curve	11
Figure 3-1. Sharp-crested Weirs	19
Figure 3-2. Flat-crested, Long-throated Flume	27
Figure 3-3. Configuration and Proportions for Parshall Flumes	29
Figure 3-4. Configuration and Proportions of Type Hs, H, and Hl Flumes	33
Figure 3-5. Lateral Mixing and Longitudinal Dispersion Patterns and Changes in Concentration Distributions from a Single, Slug Injection of a Tracer	40

LIST OF TABLES

Table 2-1. Typical Values for Manning's n	5
Table 4-1. Water Measurement Device Selection Guidelines	52
Table 4-2. Water Measurement Device Selection Criteria	57
Table 4-3. Water Measurement Device Selection; Ranking of Factors	58
Table 5-1. Accuracy and Precision Considerations for Mine Flow Measurement Methods	67
Table 5-2. Sensitivity Limitations for Different Mine Flow Measurement Methods	69
Table 5-3. Example QC Objectives for Specific Measurements	70
Table 5-4. Typical QC Objectives for Specific Measurement Device	70

LIST OF ACRONYMS

ADCPs	Acoustic Doppler Current Profilers
ADVs	Acoustic Doppler Velocimeters
AVM	Acoustic Velocity Meter
BMPs	Best Management Practices
BOR	Bureau of Reclamation
CAA	Clean Air Act
CERCLA	Comprehensive Environmental Response, Compensation, and Liability Act
cfs	Cubic Feet per Second
cms	Cubic Meters per Second
CWA	Clean Water Act
EGL	Energy Grade Line
EPA	U.S. Environmental Protection Agency
FSs	Feasibility Studies
ft/s	Feet per Second
ft ²	Square Feet
gpm	Gallons per minute
HGL	Hydraulic Grade Line
l/s	Liters per Second
LDVs	Laser Doppler Velocimeters
LiBr	lithium bromide
MDLs	Method Detection Limits
MWTP	Mine Waste Technology Program
NaBr	Sodium Bromide
NaCl	Sodium Chloride
NEPA	National Environmental Policy Act
NPDES	National Pollutant Discharge Elimination System
NRCS	U.S. Natural Resource Conservation Service
NRMRL	National Risk Management Research Laboratory
QA	Quality assurance
QA/QC	Quality Assurance/Quality Control
QAPP	Quality Assurance Project Plan
QC	Quality Control

LIST OF ACRONYMS (continued)

RI/FS	Remedial Investigations/Feasibility Studies
RI	Remedial Investigations
RPD	Relative Percent Difference
RSD	Relative Standard Deviation
SCS	Soil Conservation Service
SME	Society of Mining Metallurgy and Exploration
TMDL	Total Maximum Daily Loads
USGS	United States Geological Survey